



The

# Broadcasters' Desktop Resource

[www.theBDR.net](http://www.theBDR.net)

... edited by Barry Mishkind – the Eclectic Engineer

## A SAMPLE SETUP SCREEN FROM THE HENRY ENGINEERING SAM

Type the Alert message text here → 3 → OFF AIR

Check this box to play an Audio alert →  Audio alert 9999  Email alert

If Display Time is set to 9999, message stays on continuously until manually reset.

Set Display Time, in seconds here → 6 → EAS Alert

Check this box to send an Email alert →  Audio alert 360  Email alert

9 → Request Line

Audio alert 10  Email alert

For each Alert message, the user can enter the desired text and the textbox color. Each message also has an associated Display Time that determines how long each message is displayed before it is automatically cancelled. (It is also possible to set a message to stay on-screen permanently, until it is manually cleared.)

There are also two checkboxes for each Alert that enable optional functions: Audio and Email. By checking the Audio box, an audio message will play when the visual alert appears on-screen. SAM is supplied with a few dozen 'stock' audio messages, although you can use any mp3 audio file and link it to any Alert.

If you check the Email checkbox, SAM will send you an email when that Alert is triggered. Just connect SAM to your LAN and email will be sent using SMTP protocol. Up to three email addresses can be notified when an Alert is triggered.